

Allegro Gate Automation Au ABN: 40-095-334-526 T: 1300 980 7



122 Croyden Rd. Roleystone, W.A. Australia E: <u>info@allegrogateautomation.com.au</u> F: +08-94636082

# Coding KingGates **STYLO4K** to a gate



# Before coding

- 1. Read this page fully
- If the remote-key(s) operate more than one item, only the items you are coding, should be power and working. Please note – Systems with battery backup are always on. You may need technician to the coding. KingGates technician will programme, if power cannot be turn off, or if cannot done by any reason
- 3. Have both, a currently working (old) and the NEW remote-key(s), ready
- 4. Stand safely about 5 metres from the gate
- 5. Gate must be fully closed

#### \_\_\_\_\_

## There are two programming methods, A and B; one of it will be suitable for this gate

## A. The coding procedure

- 1. Take the NEW remote and press a button and hold it pressed for 6 seconds then release
- 2. Take the currently working (OLD) remote-key and:
- 3. press, release, wait for the red flashing indicator to turn off
- 4. press, release, wait for the red flashing indicator to turn off
- 5. press, release, wait for the red flashing indicator to turn off
- 6. Within the next 5 seconds take the NEW remote, and shortly press the desired button again
- 7. The remote is now ready to work! Check operation with the new remote
- 8. If not working repeat the above steps again

## B. <u>The coding procedure</u>

- 1. Take a working (OLD) **remote control unit** and press the large two buttons together simultaneously for 6 seconds
- 2. With few seconds take a NEW remote-key and press the two large buttons together simplistically
- 3. The new remote-key is now ready to work! Check operation with the new remote few times
- 4. If not working repeat the above steps again

#### Notes:

- 1. Some KingGates items do not support this procedure
- 2. Should you need technician for this procedure, for any reason, Technician call out fee may apply

Allegro and KingGates recommend replacement of the remote's batteries when:

- every 12 month
- or if it ceases to work
- or when the indicator light dimming.

The Warranty for remote-keys is 12 months

For any further information — please contact your installer or us. Enjoy your new remote!

## The Allegro/ King, Technical Team